



# Attach gas inlet

Written By: Tanya Taylor





## TOOLS:

- [Adjustable spanner](#) (1)
-

## Step 1 — Attach inlet



- Attach the inlet using a ¼ inch Swagelok compression fitting.

## Step 2 — Check gas flow



- [Perform a flow check](#) to make sure the inlet is fitted correctly and the sample pump is working properly.

### Step 3 — Attach filter



- Fit the supplied Kynar fitting to the Swagelok nut at the end of the sample cane. This fitting contains the mesh filter.

For further support, contact [Technical Support](#).